BrM 5.2.2 Database Conversion



BrMUG 2015 Park City, Utah

AASHTOWare Bridge Management

Significant Changes

- GUIDs
 - Globally Unique Identifier
 - Key fields replaced in DB with GUID field
- English Units Database

 All units in DB are English based
 Still able to display Metric if needed



AASHTOWare Bridge Management

GUIDS

• Globally Unique Identifier

Randomly Generated Number

• All old fields still exist!



AASHTOWare Bridge Management

GUIDS Example

	Column Name	Data Type	Allow Nulls
▶8	BRKEY	varchar(15)	
8	INSPKEY	varchar(4)	
8	ELEM_KEY	numeric(4, 0)	
8	ELEM_PARENT_KEY	numeric(4, 0)	
8	ENVKEY	numeric(1, 0)	
8	STRUNITKEY	numeric(4, 0)	
8	ELEM_GRANDPARENT_KEY	numeric(4, 0)	
		livat	
	ELEM_SCALE_FACTOR	float	\checkmark
	ELEM_PCTSTATE1	float	
	ELEM_PCTSTATE2	float	
	ELEM_PCTSTATE3	float	
	ELEM_PCTSTATE4	float	
	ELEM_QTYSTATE1	float	
	ELEM_QTYSTATE2	float	
	ELEM_QTYSTATE3	float	
	ELEM_QTYSTATE4	float	
	ELEM_DESC	varchar(255)	\checkmark
	ELEM_CREATEDATETIME	datetime	\checkmark
	ELEM_CREATEUSERKEY	varchar(4)	\checkmark
	ELEM_MODTIME	datetime	v
	ELEM_MODUSERKEY	varchar(4)	\checkmark
	ELEM_DOCREFKEY	varchar(255)	v
	ELEM_NOTES	varchar(2000)	v
			_

	Column Name	Data Type	Allow Nulls
▶8	PON_ELEM_INSP_GD	varchar(32)	
	BRKEY	varchar(15)	V
	INSPKEY	varchar(4)	V
	ELEM_KEY	numeric(4, 0)	V
	ELEM_PARENT_KEY	numeric(4, 0)	V
	ENVKEY	numeric(1, 0)	V
	STRUNITKEY	numeric(4, 0)	V
	ELEM_GRANDPARENT_KEY	numeric(4, 0)	V
	ELEM_QUANTITY	float	
	ELEM_SCALE_FACTOR	float	V
	ELEM_PCTSTATE1	float	
	ELEM_PCTSTATE2	float	
	ELEM_PCTSTATE3	float	
	ELEM_PCTSTATE4	float	
	ELEM_QTYSTATE1	float	
	ELEM_QTYSTATE2	float	
	ELEM_QTYSTATE3	float	
	ELEM_QTYSTATE4	float	
	ELEM_DESC	varchar(255)	V
	ELEM_CREATEDATETIME	datetime	V
	ELEM_CREATEUSERKEY	varchar(4)	V
	ELEM_MODTIME	datetime	V
	ELEM_MODUSERKEY	varchar(4)	V
	ELEM_DOCREFKEY	varchar(255)	V
	ELEM_NOTES	varchar(3999)	
1	PON_ELEM_INSP_LB	varchar(50)	
	PON_ELEM_DEFS_GD	varchar(32)	
	PON_ENVT_DEFS_GD	varchar(32)	
	INSPEVNT_GD	varchar(32)	
	STRUCTURE_UNIT_GD	varchar(32)	
	PARENT_PON_ELEM_INSP_GD	varchar(32)	V
	BRIDGE_GD	varchar(32)	
		1	

AASHTOWare Bridge Management

Views To The Rescue

• Added views that mimic 5.2.1 tables

- Views for following tables
 - BRIDGE
 - INSPEVNT
 - PON_ELEM_INSP
 - ROADWAY
 - STRUCTUNIT

AASHTOWare Bridge Management

English Based Units

• All unit fields converted to English

- Conversion done through the PAIRCODE

 Links to METRIC_ENGLISH field
- No going back
 - Check your PAIRCODES!

AASHTOWare Bridge Management

Script Based Options

Ability to change what script does

Each option has different options

No going back
 – Verify your options!



AASHTOWare Bridge Management

Script Based Options

-- Turn on or off parts of the upgrade. Please refer to documents for more details. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('ARCHIVE_PON_ELEM_INSP', 'DEFAULT'); -- DEFAULT | ALWAYS | NEVER INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('INSERT_STANDARD_BENEFITS_ACTIONS', 'DEFAULT'); -- DEFAULT | SKIP INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('CONVERT_METRIC_TO_ENGLISH', 'ON_(ONLY_COLUMNS_IN_PON_DICT)'); --INSERT INTO PON GLOB VAR (VARI, VAR VALUE) VALUES ('FORWARD ELEMS FOR BLANK INSP', 'ON'); -- ON | OFF

-- Turn on or off parts of the scripts. These will cause scripts to fail and are to be used for debugging. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('PCB', 1); -- Pre-Clean up INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('TSC', 1); -- Schema update/creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('PUP', 1); -- Grant 'PONTISUSER' permissions to new tables. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('DDV', 1); -- Default Data verification. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('DDV', 1); -- Force Set Default Data. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('SUI', 1); -- Force Set Default Data. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('SUI', 1); -- Index update/creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('SUI', 1); -- Primary Key creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('SFK', 1); -- Foreign Key creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('SFK', 1); -- Foreign Key creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('STG', 1); -- Views creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('STG', 1); -- Triggers creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('STG', 1); -- Procedures creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('PDR', 1); -- Procedures creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('PDR', 1); -- Functions creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('PDR', 1); -- Functions creation. INSERT INTO PON_GLOB_VAR (VARI, VAR_VALUE) VALUES ('PCA', 1); -- Functions creation.

AASHTOWare Bridge Management

Script Checks

• Pre-migration checks to validate data

Will give suggestions for corrections

Scripts have not completed if checks hit!



AASHTOWare Bridge Management

Script Checks

Msg 50000, Level 16, State 1, Line 42

!!! SCRIPTS STOPPED DUE TO CUSTOM OBJECTS EXISTING THAT WOULD PREVENT SUCCESSFUL UPGRADE. !!! Errors will occur during the update process for BRM522RC2. Due to the switch to GUID, objects t ALTER TABLE BMSROCK_HEADER DROP CONSTRAINT FK_BMSROCK_HEADER_BRIDGE; -- Execute this statement ALTER TABLE BMSORGSTR_HEADER DROP CONSTRAINT FK_BMSORGSTR_HEADER_BRIDGE; -- Execute this statem ALTER TABLE BMS_RATG_EVNT_PUBD DROP CONSTRAINT FK_BMS_RATG_EVNT_PUBD_BRIDGE; -- Execute this statement ALTER TABLE BMS_CBI_2_DAY_HIST DROP CONSTRAINT FK_BMS_CBI_2_DAY_HIST_PON_APP_USERS; -- Execute ALTER TABLE BMSSCPEV_HEADER DROP CONSTRAINT FK_BMSSCPEV_HEADER_BRIDGE; -- Execute this statement ALTER TABLE BMSSNDEL_HEADER DROP CONSTRAINT FK_BMSSNDEL_HEADER_BRIDGE; -- Execute this statement ALTER TABLE BMSSNDEL_HEADER DROP CONSTRAINT FK_BMSSNDEL_HEADER_BRIDGE; -- Execute this statement ALTER TABLE BMSSNDEL_HEADER DROP CONSTRAINT FK_BMSSNDEL_HEADER_BRIDGE; -- Execute this statement ALTER TABLE BMSSNDEL_HEADER DROP CONSTRAINT FK_BMS_ST_SPEC_EQ_BRIDGE; -- Execute this statement ALTER TABLE BMS_ST_SPEC_EQ DROP CONSTRAINT FK_BMS_ST_SPEC_EQ_BRIDGE; -- Execute this statement ALTER TABLE BMS_ST_SPEC_INSP DROP CONSTRAINT FK_BMS_ST_SPEC_INSP; -- Execute this statement bef ALTER TABLE BMS_RATG_EVNT_HST DROP CONSTRAINT FK_BMS_RATG_EVNT_HST_BRIDGE; -- Execute this statement bef ALTER TABLE BMS_RATG_EVNT_HST DROP CONSTRAINT FK_BMS_RATG_EVNT_HST_BRIDGE; -- Execute this statement bef ALTER TABLE BMS_RATG_EVNT_HST DROP CONSTRAINT FK_BMS_RATG_EVNT_HST_BRIDGE; -- Execute this statement bef ALTER TABLE BMS_RATG_EVNT_HST DROP CONSTRAINT FK_BMS_RATG_EVNT_HST_BRIDGE; -- Execute this statement bef ALTER TABLE BMS_RATG_EVNT_HST DROP CONSTRAINT FK_BMSBRDET_HEADER_BRIDGE; -- Execute this statement bef ALTER TABLE BMSBRDET_HEADER DROP CONSTRAINT FK_BMSBRDET_HEADER_BRIDGE; -- Execute this statement bef ALTER TABLE BMSBRDET_HEADER DROP CONSTRAINT FK_BMSBRDET_HEADER_BRIDGE; -- Execute this statement bef ALTER TABLE BMSBRDET_HEADER DROP CONSTRAINT FK_BMSBRDET_HEADER



AASHTOWare Bridge Management

ERD Diagram

• ERD diagram for 5.2.2 DB


• Fully updated for 5.2.2 database

Included with the documentation



AASHTOWare Bridge Management

ERD Diagram



AASHTOWare Bridge Management

Questions

Website: <u>www.aashtowarebridge.com</u>

JIRA: <u>https://bridgeware.atlassian.net/</u>

Email: <u>BrM@bentley.com</u>



AASHTOWare Bridge Management